

**Benefits:**

- Self-adhesive for easy application – no taping required.
- Lightweight, easy-to-handle rolls.
- High tear & puncture resistance.
- 100% waterproof.
- Easy to cut with a knife.
- Personalized logo and branding printing available (Minimum quantities applicable)

Perfect for reducing clean up time at the end of a building, painting, or DIY project. It is a 100% waterproof, high-quality self-adhesive film designed specifically for the protection of windows, glazed panels, and window frames. Windows are highly susceptible to scratches, plaster and paint splashes especially during external rendering, paint spraying and decorating projects. Self-adhesive protective film for windows can help you avoid the additional cost of extensive cleaning or window replacement.

The lightweight self-adhesive film rolls are forward wound (adhesive side is inner-side) which makes the rolls perfect for application with our Qualitape Window Film Applicator or by hand. As the adhesive is on the inner-side near it is not exposed so as to collect dirt. The low tack adhesive backing sticks to most hard surfaces without any tape required and will stay securely in place once applied. After use, it can be peeled away without leaving any residue which can be a problem with poor quality films. Unlike some alternative products Qualitape Window Protector roll has Anti-UV properties to ensure that direct sunlight does not cause the adhesive to transfer onto the windows.

Limitations:

- Product may become slippery when wet. Mop up any spills immediately or replace where necessary.
- This product is for application to windows and other glass surfaces. DO NOT use on carpets. Use Qualitape Carpet Protection film.
- Obviously, adhesion will be reduced on dusty surfaces. Vacuuming prior to use is recommended.
- Qualitape Window Protection Film should be removed after a maximum of 40 days.
- Always check Qualitape Window Film is stuck firmly to windows before commencing work.
- Do not use heated windows whilst product is in situ.
- On delicate surfaces, we advise that you test on a small area first.
- It is the users' responsibility to determine suitability for use. If in doubt, contact technical services for advice.
- Not fire-retardant.

Application:

Ensure surfaces to which Qualitape Window Protection Film is to be applied are clean sound, dust free and dry. Remove outer packaging from roll. Unwind approx. 600mm of material and stick this to the top of the window pulling the roll down towards the floor. Ensure the roll is stuck by smoothing out by either hand or foot. Simply pull the roll down towards the floor ensuring it goes in a straight line. Smooth out with hands as it unwinds.

Performance Data:

Temperature Resistance	60°C 160hours
Tensile Strength	≥10 N/mm
Adhesive	Pressure Sensitive Acrylic
Adhesive Strength	250g / 50mm
UV Resistance	Up to 6 months
Slip Characteristics	64PTV - Low risk
Backing	PE(LDPE and LLDPE) film

