



How to Safely Empty and Dispose of a Disposable Canister

1. Ensure operators are wearing the required PPE including; safety goggles, protective gloves and protective clothing.

2. Canisters contain compressed gas and are only considered empty after opening the valve carefully to vent any excess adhesive or pressure. Operators must be **100%** sure that no product or gas is left in the canister before continuing.



3. Once all the contents have been expelled; locate the circular plug on the top of the canister shown opposite.



4. Puncture a hole in the plug on the canister using a hammer and a non-sparking brass punch or any other **non-sparking object** that can be used as a punch.



5. The empty canisters are now accepted by steel recycling facilities and landfills, but it is suggested to follow any regulations before disposing or recycling canisters.